



# How To Remove and Install Bottom Speed Sensor Switch on Compressor



### TOOLS NEEDED

7mm Socket and Ratchet

1. Locate wiring harness on compressor that came off vehicle. Disconnect/unplug wire going to clutch.
2. Locate Switch on bottom of the compressor that came off the vehicle.



3. Remove 2 x 7 mm bolts on switch.
4. Remove switch from compressor that came off the vehicle.
5. Locate switch cover on bottom of gpd. Slightly loosen the discharge port on the gpd compressor to release any pressure before removing the switch plate and blank. Retighten the port cover to insure no oil is lost from compressor.
6. Remove cover with 2 x 7mm bolts



Manufacturer names, logos and part numbers are for reference only. All prices, taxes and availability are subject to change without notice. This document and any files transmitted with it are confidential and intended solely for the use of the individual or entity to which they are addressed. If you have received this document in error, please delete it immediately. Note that any views or opinions presented in this document are solely those of the author. Any unauthorized review, use, disclosure, or distribution is prohibited. Global Parts Distributors, LLC (gpd) accepts no liability for any damage caused by any virus or other means transmitted by this document. © Global Parts Distributors, LLC (gpd)

# How To Remove and Install Bottom Speed Sensor Switch on Compressor




Global Parts Distributors, LLC

TECH TIP


#40

gpdtechtips.com


7. Remove blank cover inside
8. Place switch inside gpd compressor and tighten 2 x 7mm bolts.



9. Place electrical connector on bracket.



10. Connect switch electrical connector to gpd compressor.



Manufacturer names, logos and part numbers are for reference only. All prices, taxes and availability are subject to change without notice. This document and any files transmitted with it are confidential and intended solely for the use of the individual or entity to which they are addressed. If you have received this document in error, please delete it immediately. Note that any views or opinions presented in this document are solely those of the author. Any unauthorized review, use, disclosure, or distribution is prohibited. Global Parts Distributors, LLC (gpd) accepts no liability for any damage caused by any virus or other means transmitted by this document. © Global Parts Distributors, LLC (gpd)