



Orifice Tubes: The Color Matters

Evaporator Mount



3411241
Blue



3411243
White



3411247
Red



3411251
Brown



3411902
*Maroon/
Black*



3411302
*Maroon/
Black*



3411254
Green



3411250
Orange



3411302
Variable Evap.



3411505
Yellow



3411885
Black



3411484
Orange

Liquid Line Mount



3411255
*Gray
PPOT*



3411253
Yellow



3411884
*Dark Gray
PPOT*



3411503
*Black
PPOT*

Condenser Mount



3411249
Black



3411252
Purple



3411296
*Yellow/
White*



3411504
Orange



3411303
*Maroon/
Black*



3411552
Orange

When deciding which orifice tube you should use, remember that color is important. Orifice tube colors identify orifice diameters. Substitution of different color orifice tubes will not work. For example, a white orifice tube cannot be substituted for a yellow or red orifice tube for blue in a Ford. Always follow the manufacturer's recommendations for the exact color and fit.