

Orifice Tubes: The Color Matters



3411241

Blue



3411243

White



3411247

Red



3411251

Brown



3411902

Maroon/Black



3411302

Maroon/Black



3411254

Green



3411250

Orange



3411302

Variable Evap.



3411505

Yellow



3411885

Black



3411484

Orange

Liquid Line Mount



3411255

Gray PPOT



3411253

Yellow



3411884

Dark Gray

PPOT



3411503

Black

PPOT

Condenser Mount



3411249

Black



3411252

Purple



3411296

Yellow/White



3411504

Orange



3411303

*Maroon/
Black*



3411552

Orange

When deciding which orifice tube you should use, remember that color is important. Orifice tube colors identify orifice diameters. Substitution of different color orifice tubes will not work. For example, a white orifice tube cannot be substituted for a yellow or red orifice tube for blue in a Ford. Always follow the manufacturer's recommendations for the exact color and fit.