

Rear Expansion Valve Hardware Kit



On specific Town and Country/Voyager/Caravan applications, the rear expansion valve retaining hardware is reusable from one repair to the next. With age/road grime, salt and wear/tear, the hardware can become chemically bonded to the evaporator pipes. The gpd rear expansion valve hardware kit can be used to replace the unusable OE version.

Tools Needed:

- 4 mm hex

Always use eye protection!

Items Needed:

- Rear Expansion Valve Kit
- Expansion Valve
- Evaporator



2. Place the clip on the lines of the evaporator (as shown above.)



1. Place the clip on the lines of the evaporator (as shown above.)



3. Connect the expansion valve to the lines making sure it is turned the proper direction.



4. Connect the expansion valve to the hardware by using a 4 mm hex to install the screws



This side faces the return lines.



This side faces the rear expansion valve hardware kit.

Two rear expansion valve hardware kits:

- 1028286 (2006–2011)
- 1028308 (2012–2015)